

Instructions:

Kit Includes:

- 1x Blowsion Flywheel Cover.
- 1x O-ring.
- 7x M6 x 16mm Stainless Steel Bolts .

Tools Required:

- 10mm Socket
- Ratchet
- 5mm Allen key

- **Step 1** - Remove the seven 10mm bolts that hold the OEM Yamaha flywheel cover on.
- **Step 2** - Remove the OEM Yamaha Flywheel Cover (make sure the 2 dowel pins remain in the crank cases)
- **Step 3** - Remove all existing gasket material
- **Step 4** - Remove the Bendix spring and washers then install them on the Blowsion Flywheel cover. Use grease to help hold them in place.
- **Step 5** - Install the Blowsion flywheel cover. Make sure that the o-ring is fully seated into the o-ring groove. Use Blue Loctite on the seven stainless steel bolts supplied. Torque bolts to 77 in/lbs in a cross pattern making sure that the bendix is not put in bind by keeping cover square with the cases when tightening.