

Parts Supplied:

- WR04009 Silicone Hose

IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

INSTALLATION INSTRUCTIONS:

1. Make sure ski is secure and on a flat surface. Remove lanyard and disconnect battery.
2. Remove OEM cross over hose from water box to sound baffle. Retain OEM clamps.



3. Remove sound suppression baffle straps and elbow hose connected to thru-hull fitting. Discard baffle. Retain OEM clamp.



4. Install WORX Silicone hose to outlet and waterbox and secure with OEM clamps. DO NOT overtighten clamps.



5. Check ski for tools etc. Re-connect battery and run on flush hose to check for leaks.