

# **WORX RACING COMPONENTS**

Pty Ltd A.C.N. 073 435 033

1/12 Ereton Drive Labrador Queensland Australia 4215

Phone: 61 7 5537 7181 Fax: 61 7 5537 7381

## **INSTALLATION INSTRUCTIONS**

**PART NUMBER : WR214    WORX MAXILOADER INTAKE GRATE**

**YAMAHA :GP 1200, XL 1200 , VENTURE 1100, RAIDER 1100**

**IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION**

Tools necessary for installation:

10mm Socket Wrench

Tube of clear silicone

Parts Supplied:

1 x **Worx Intake Grate**

8 x 20mm x 6mm stainless socket head bolts

1 x Allen key

- 1 Remove stock intake grate and wipe clean any old silicone or loctite from mounting bolt holes and threads
2. Fill threads with silicone and apply silicone to the front and rear mounting surfaces and edges of your new **Worx Intake Grate**
- 3 Fit **Worx Intake Grate** into position using the new mounting bolts supplied.
- 4 Wipe off excess silicone with a damp cloth. Allow 4-6 hours minimum for silicone to cure before riding.
5. Regularly check that all bolts are tight on your intake grate and ride plate.

Thank you for purchasing **Worx Racing Components** Products. We firmly believe that **Worx Racing Components** Products are among the finest watercraft parts available.

A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure.

If you have any questions or comments on the performance and /or installation of our products, please contact us at the above numbers.

**RIDE SAFELY PROTECT OUR ENVIROMENT  
AND RESPECT OTHERS WHO SHARE OUR WATERWAYS**

*'Personal watercraft accessories'*  
**FOR THE PERFORMANCE EDGE**