

WORX RACING **WORX COMPONENTS**

Pty Ltd A.C.N. 073 435 033

1/12 Ereton Drive Labrador Queensland Australia 4215

Phone: **61 7 5537 7181** Fax: 61 7 5537 7381

INSTALLATION INSTRUCTIONS

PART NUMBER : WR217 WORX MAXILOADER INTAKE GRATE SEADOO All RX

IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

Tools necessary for installation:

10mm Socket Wrench

13mm Socket Wrench

Tube of clear silicone

Parts Supplied:

1 x **Worx Intake Grate**

1. Remove stock intake grate and wipe clean any old silicone or loctite from hull and threaded inserts.
2. Fill threaded inserts with silicone and apply a small amount of silicone to the front mounting surface and a generous amount of silicone to the front and rear mounting surfaces of your new **Worx Intake Grate**
3. Fit **Worx Intake Grate** into position using the stock mounting bolts.
4. Wipe off excess silicone with a damp cloth. Allow 4-6 hours minimum for silicone to cure before riding.
5. Regularly check that all bolts are tight on your intake grate and ride plate.

Thank you for purchasing **Worx Racing Components** Products. We firmly believe that **Worx Racing Components** Products are among the finest watercraft parts available.

A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure.

If you have any questions or comments on the performance and/or installation of our products, please contact us at the above numbers.

RIDE SAFELY PROTECT OUR ENVIROMENT
AND RESPECT OTHERS WHO SHARE OUR WATERWAYS