PART NUMBER : WR227 WORX MAXILOADER INTAKE GRATE KAWASAKI 2007 on ULTRA, 250 / ULTRA, LX

IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

Tools necessary for installation: 1 x Small Tube of Silicone

Parts Supplied: 1 x Worx Intake Grate

2 x M6 x 50mm Socket Head Cap Screws

2 x m6 Flat Washers 1 x 5mm Allen Key

- 1. Remove the stock grate using the 5mm allen key provided and wipe clean any old silicone from hull.
- 2. Fill threaded inserts with silicone and apply a small amount of silicone to both mounting surfaces and the back of your new **Worx** Intake Grate where it fits up into the pump shoe.
- 3 Fit **Worx** Intake Grate into position using four of the stock bolts in the back of the grate and the two longer bolts and flat washers supplied in the front mounting holes.
- 4 Wipe off excess silicone with a damp cloth. Allow 4-6 hours minimum for silicone to cure before riding.
- 5. Regularly check that all bolts are tight on your intake grate and ride plate.

Thank you for purchasing **Worx Racing Components** Products. We firmly believe that **Worx Racing Components** Products are among the finest watercraft parts available.

A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure.

If you have any questions or comments on the performance and/or installation of our products, please contact us at the above numbers.

RIDE SAFELY PROTECT OUR ENVIROMENT
AND RESPECT OTHERS WHO SHARE OUR WATERWAYS