



MADANT DARSHEL PTY LTD

1/12 Ereton Drive Labrador Queensland Australia 4215

Phone: +61 7 55377181

Fax: +61 7 5537 7381

INSTALLATION INSTRUCTIONS

PART NUMBER : **WR228** **WORX MAXILOADER INTAKE GRATE** **YAMAHA SUPERJET 2008 on.**

IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

Tools necessary for installation:	10mm Hex Wrench
Parts Supplied:	1 x WORX Intake Grate 1 x 5mm Allen Key 2 x 20mm x 6mm Allen Head Bolts 2 x 12mm x 6mm Allen Head Bolts

- 1 . Put ski on a flat surface
 - . Roll onto left side (refer to manufacturers instructions)
 - . Remove stock intake grate using 10mm hex wrench and wipe clean any old silicone or from hull and threaded inserts.
2. Fill threaded inserts with silicone and apply a small amount of silicone to both mounting surfaces of your new **Worx** Intake Grate.
- 3 Fit **Worx** Intake Grate into position using the Allen Headed bolts and Allen key supplied:
Important Use the shorter (12mm) bolts in the rear mounting holes
Failure to do this could cause damage to pump housing, tighten with Allen key supplied
- 4 Wipe off excess silicone with a damp cloth. Allow 4-6 hours minimum for silicone to cure before riding.
5. Regularly check that all bolts are tight on your intake grate and ride plate.

Thank you for purchasing **Worx Racing Components** Products. We firmly believe that **Worx Racing Components** Products are among the finest watercraft parts available.

A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure.

If you have any questions or comments on the performance and/or installation of our products, please contact us at the above numbers.

RIDE SAFELY PROTECT OUR ENVIROMENT
AND RESPECT OTHERS WHO SHARE OUR WATERWAYS