

WORX RACING WORX COMPONENTS

Pty Ltd A.C.N. 073 435 033

1/12 Ereton Drive Labrador Queensland Australia 4215

Phone: 61 7 5537 7181 Fax: 61 7 5537 7381

INSTALLATION INSTRUCTIONS

PART NUMBER : WR518

WORX RACE SPONSONS

SEADOO : GTS, -96 GTX, -97 GTI

IMPORTANT : READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

Tools necessary for installation :

Large Phillip's (Star) screwdriver
¼" Drill Bit
10mm Socket and Extension
11mm Socket and Extension
1 x Tube of silicone

Parts Supplied :

2 x **Worx** adjustable Sponsons
2 x Side rails
2 x ¾" x ¼" Round head bolts
8 x 1" x ¼" Round head bolts
8 x 1 ¼" x ¼" Round head bolts
8 x 9/16" x ¼" Flat washers
10 x ¾" x ¼" Flat Washers
8 x Nut / washer Combo
2 x ¼" Nyloc nuts

1. remove stock sponsons using the 10mm socket and extension you will need to remove water box left side of the hull and disconnect the exhaust hose on the right side to gain access to nuts on the inside of hull. (5 each side)
2. Fit the two ¾" x ¼" Round head bolts into the front mounting hole on each side of the boat (the sponsons only use the four rear holes) apply a small amount of silicone around the head of each bolt, use a ¾" flat washer and a nyloc on the inside of the hull
3. Apply a bead of silicone around edges of side rails and around each mounting hole on the hull.
Important Rails are tapered to fit the angle of the sides of the hull make sure that you fit them with the shaped end forward and the cut away facing down.
4. Fit side rails to hull using the 8 x 1 ¼" x 1" round head bolts with the 9/16" flat washers and the nut washer combo on the inside using the 11mm socket/ extension and the screwdriver

Cont P.T.O.

WR518

< 2 >

- 5 Fit the Sponsons using the 8 1¹/₄" round head bolts and the 3/4" flat washers.
- 6 Adjust sponsons to suit your riding style
 - Top set of holes to suit novice and recreational riders
 - Second set of holes recommended for experienced riders and racers.
 -
- 7 Recheck that the bolts holding the sponsons onto the side rails are tight after 15 minutes riding. When you have decided which position best suits your riding style it is recommended that you apply red loctite to the bolts to ensure that they do not work loose, regularly check that the bolts are tight.
9. **Warning :** These sponsons will vastly improve the turning capability of your boat take time to get used to them before you attempt any hard cornering.

Thank you for purchasing **Worx Racing Components** products. We believe that **Worx Racing Components** products are among the finest watercraft parts available.

A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation will be a relatively straight forward procedure. If you have any comments on the performance/or installation of our parts, please contact us on the numbers listed on page one or through your local dealer.

Note: These sponsons comply with I.J.S.B.A. regulations. Please check with your country's governing body for eligibility for your class of racing

RIDE SAFELY, PROTECT OUR ENVIRONMENT
AND RESPECT OTHERS WHO SHARE OUR WATERWAYS